

Dimension: 1.82" w x 0.36" h

V-T-10

WATERPROOF T-MOLDING

Used to fill the gap between two floors of equal height.

Used with floors ranging from 8-12mm in height.

For concrete use appropriate Rawl Plugs (Not Included)

Glue with construction adhesive (do not glue floor)

Surface: Wear resistant

1

Install the flooring leaving a 1 1/8" gap between the two floors for the t-molding installation.

2


Measure and trim to fit.

3

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor.
(or glue down with construction adhesive).
** May need to use supplied shim*

4

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.



Dimension: 1.77" w x 0.28" h

V-T-14

WATERPROOF T-MOLDING

Used to fill the gap between two floors of equal height.

Used with floors ranging from 2-6mm in height.

For concrete use appropriate Rawl Plugs (Not Included)

Glue with construction adhesive (do not glue floor)

Surface: Wear resistant

1

Install the flooring leaving a 1-1/8" gap between the two floors for the t-molding installation.

2


Measure and trim to fit.

3

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor. *(or glue down with construction adhesive).*

4

Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once. You may also use a rubber mallet.*



Dimension: 1.82" w x 0.36" h

V-T-18

WATERPROOF T-MOLDING

Used to fill the gap between two floors of equal height.

Used with floors ranging from 6-9mm in height.

For concrete use appropriate Rawl Plugs (Not Included)

Glue with construction adhesive (do not glue floor)

Surface: Wear resistant

1

Install the flooring leaving a 1-1/8" gap between the two floors for the t-molding installation.

2

Measure and trim to fit.

3

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor. (or glue down with construction adhesive).

4

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.