

**Dimension:** 1.89" w x 0.50" h

# V-SR-10

## WATERPROOF SURFACE REDUCER

Used to fill the gap between two floors of unequal height.

Used with floors ranging from 8-12mm height.

*For concrete use appropriate Rawl Plugs (Not Included)*

*Glue with construction adhesive (do not glue floor)*

**Surface:** Wear resistant

**1**

Install the flooring leaving a 1-1/8" gap between the two floor surfaces for the surface reducer installation.

**2**


Measure and trim to fit.

**3**

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor. (or glue down with construction adhesive). \*You may need to use the supplied shim.

**4**

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.



**Dimension:** 1.77" w x 0.345" h

# V-SR-14

## WATERPROOF SURFACE REDUCER

Used to fill the gap between two floors of unequal height.

Used with floors ranging from 2-6mm height.

*For concrete use appropriate Rawl Plugs (Not Included)*

*Glue with construction adhesive (do not glue floor)*

**Surface:** Wear resistant

**1**

Install the flooring leaving a 1-1/8" gap between the two floor surfaces for the surface reducer installation.

**2**


Measure and trim to fit.

**3**

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor. (or glue down with construction adhesive).

**4**

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.



**Dimension:** 1.89" w x 0.50" h

# V-SR-18

## WATERPROOF SURFACE REDUCER

Used to fill the gap between two floors of unequal height.

Used with floors ranging from 6-9mm height.

*For concrete use appropriate Rawl Plugs (Not Included)*

*Glue with construction adhesive (do not glue floor)*

**Surface:** Wear resistant

**1**

Install the flooring leaving a 1-1/8" gap between the two floor surfaces for the surface reducer installation.

**2**

Measure and trim to fit.

**3**

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor. (or glue down with construction adhesive).

**4**

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.